

Attention Innovate Security For Life Customers:

Since you have invested in the highest quality security system on the market your account will be monitored and connected to public safety agencies. Every city has different permitting standards for monitored security systems. Make sure to check with your local city clerk's office or police station to find out if you need a permit for this monitored system.

UNBOXING:

Hello and welcome to Innovate SFL. The purpose of this QuickStart guide is to make the installation and activation of your system as easy as possible. Please begin by reviewing your zone list to make sure all of your components and corresponding magnetic mounts have been included. Remember your components arrive pre-integrated with magnets.

Before applying adhesive to any surface it is our recommendation that you wipe the surfaces down with a damp towel followed by a dry one. Make sure the surface is free of all dust and debris and you allow time to dry completely.

Before magnetically attaching your new security system permanently, it is our recommendation that you allow 24 hours to maximize bond strength. For maximum cure time leave for 72 hours, particularly on ceiling mounted items.

PANEL INSTALLATION:

-IF PLACED ON A FLAT SURFACE: Attach the table stand on the back of the panel in the two large holes provided. Push up until you hear a "click" and then power on the system by pressing the power button for three seconds.

-FOR WALL INSTALLATION: Using the provided template. Take two pieces of scotch tape, and place the template on the wall where you wish to locate the panel. Peel the backing off of the mounts and place the mounts in the cut out areas. Make sure to press firmly for 10 seconds. After that, mount the panel and plug it in. Press the power button for three seconds to power on.

PLACING SENSORS:

-Glassbreak: You should place at least 3.3 feet (1 meter) opposite of any of the windows that you want to protect, for optimal detection. Peel and place the magnetic mount on the wall area and press/hold for 10 seconds, and then mount the glass break sensor.

-Motion Sensors: Peel and place the magnetic mount in the desired area for motion sensor placement. Place the motion sensor in an area where it gets a clear view of the area and make sure the device is free of obstruction. Put at a height of roughly 6.5 feet.

-Do you have pets? Please understand that there is always the possibility that even small pets may trigger a false alarm.

-Window Sensors: When installing the sensor on a window, place the thinner piece on the part of the window that moves, to reduce possibility of damage to the sensor as you open and close the window. If your window does not allow this kind of installation then you can reverse this configuration.

-Door sensors: When installing the sensor on a door, place the thinner piece on the door itself and the larger sensor on the door frame. If the trim around your door does not allow this kind of installation then you may reverse this configuration. Remember to place the sensor **OPPOSITE** of the door hinges, on the handle side. Position the sensors **NO MORE THAN 3/4** of an inch away from each other and it is wise to mount high enough to be out of the range of children and pets.

-Smoke/CO Detectors: All smoke detectors and CO detectors are to be wall mounted less than 12" from the ceiling. Peel and place the mount on the desired area and hold the mount for 30 seconds. Your device should be flashing a green light, meaning its ready to be activated. Finally center the device on the magnetic mount.

START/WIZARD:

-Swipe down to access settings, advanced, enter your user code (default code is 1111), run a cell test, connect to wifi, check for updates.

NEED ASSISTANCE?

If you need any assistance with parts, installation, or have other questions, please reach out to us at

800-996-8109